


















































| Explanation                                       | Colour, symbol  | Button plates<br>for push-buttons     |                                       |                         | Colour, symbol  | Transparent insert plates<br>for illuminated push-buttons and indicator light, flush |                                       |                         | Std. pack |
|---|---|---------------------------------------|---------------------------------------|-------------------------|---|--|---------------------------------------|-------------------------|-----------|
|   |   | 18 × 18 mm<br>Part no.<br>Article no. | 25 × 25 mm<br>Part no.<br>Article no. | Price<br>see price list |   | 18 × 18 mm<br>Part no.<br>Article no.  | 25 × 25 mm<br>Part no.<br>Article no. | Price<br>see price list |           |
| <b>Marking plates</b>                             |   |                                       |                                       |                         |   |  |                                       |                         |           |
|   |    | <b>01TQ18</b><br>086816               | <b>01TQ25</b><br>091121               |                         |    | <b>01LQ18</b><br>090231  | <b>01LQ25</b><br>093180               |                         | 20        |
|   |    | <b>02TQ18</b><br>086859               | <b>02TQ25</b><br>091149               |                         |   |  |                                       |                         |           |
|   |    | <b>03TQ18</b><br>087766               | <b>03TQ25</b><br>091184               |                         |   |  |                                       |                         |           |
|   |    | <b>04TQ18</b><br>087834               | <b>04TQ25</b><br>091442               |                         |   |  |                                       |                         |           |
|   |    | <b>05TQ18</b><br>087867               | <b>05TQ25</b><br>091471               |                         |   |  |                                       |                         |           |
|   |    | <b>06TQ18</b><br>087920               | <b>06TQ25</b><br>091506               |                         |   |  |                                       |                         |           |
| With inscription to order via Label-editor → Note |    | <b>XQ18D-*.*</b><br>285286            |                                       |                         |    | <b>XQ25D-*.*</b><br>285287   |                                       |                         | 1         |
| OFF   |    | <b>10TQ18</b><br>087951               | <b>10TQ25</b><br>091536               |                         |    | <b>10LQ18</b><br>090243  | <b>10LQ25</b><br>093225               |                         | 20        |
| STOP or OFF                                       |    | <b>19TQ18</b><br>054510               | <b>19TQ25</b><br>054508               |                         |   |  |                                       |                         |           |
| ON  |    | <b>11TQ18</b><br>088007               | <b>11TQ25</b><br>091562               |                         |    | <b>11LQ18</b><br>090288  | <b>11LQ25</b><br>093242               |                         |           |
| START or ON                                       |    | <b>20TQ18</b><br>054509               | <b>20TQ25</b><br>054507               |                         |   |  |                                       |                         |           |
| START or ON                                       |  | <b>21TQ18</b><br>088061               | <b>21TQ25</b><br>091586               |                         |   |  |                                       |                         |           |
| Direction of movement                             |  | <b>32TQ18</b><br>088125               | <b>32TQ25</b><br>091618               |                         |  | <b>32LQ18</b><br>090320  | <b>32LQ25</b><br>093264               |                         |           |
| Direction of movement                             |  | <b>36TQ18</b><br>088275               | <b>36TQ25</b><br>092592               |                         |  | <b>36LQ18</b><br>090410  | <b>36LQ25</b><br>093330               |                         |           |
| Electr. voltage                                   |  | <b>34TQ18</b><br>095386               | <b>34TQ25</b><br>092563               |                         |  | <b>34LQ18</b><br>090368  | <b>34LQ25</b><br>093307               |                         |           |
| Increase  |  | <b>37TQ18</b><br>088315               | <b>37TQ25</b><br>092608               |                         |  | <b>37LQ18</b><br>090434  | <b>37LQ25</b><br>093365               |                         |           |
| Decrease  |  | <b>38TQ18</b><br>088340               | <b>38TQ25</b><br>092645               |                         |  | <b>38LQ18</b><br>090488  | <b>38LQ25</b><br>093402               |                         |           |
| Hand  |  | <b>40TQ18</b><br>088389               | <b>40TQ25</b><br>092709               |                         |  | <b>40LQ18</b><br>086178  | <b>40LQ25</b><br>093462               |                         |           |
| Automatic   |  | <b>41TQ18</b><br>088412               | <b>41TQ25</b><br>092774               |                         |  | <b>41LQ18</b><br>086210  | <b>41LQ25</b><br>093528               |                         |           |
| ON-OFF, spring-return                             |  | <b>43TQ18</b><br>088426               | <b>43TQ25</b><br>092791               |                         |  | <b>43LQ18</b><br>086246  | <b>43LQ25</b><br>090501               |                         |           |
| Unlock  |  | <b>52TQ18</b><br>088452               | <b>52TQ25</b><br>092825               |                         |  | <b>52LQ18</b><br>086366  | <b>52LQ25</b><br>090640               |                         |           |
| Lock  |  | <b>53TQ18</b><br>088487               | <b>53TQ25</b><br>092874               |                         |  | <b>53LQ18</b><br>086453  | <b>53LQ25</b><br>090676               |                         |           |
| Unclamp   |  | <b>54TQ18</b><br>088512               | <b>54TQ25</b><br>093013               |                         |  | <b>54LQ18</b><br>086755  | <b>54LQ25</b><br>090706               |                         |           |
| Clamp   |  | <b>55TQ18</b><br>088545               | <b>55TQ25</b><br>093032               |                         |  | <b>55LQ18</b><br>086817  | <b>55LQ25</b><br>090737               |                         |           |
| Liquid START                                      |  |                                       | <b>921TQ25</b><br>047426              |                         |   |  |                                       |                         |           |
| Liquid STOP                                       |  | <b>63TQ18</b><br>088566               | <b>63TQ25</b><br>093060               |                         |  | <b>63LQ18</b><br>086861  | <b>63LQ25</b><br>090776               |                         |           |
| Klaxon  |  | <b>66TQ18</b><br>088590               | <b>66TQ25</b><br>093092               |                         |  | <b>66LQ18</b><br>087800  | <b>66LQ25</b><br>090799               |                         |           |
| Spindle START                                     |  |                                       | <b>811TQ25</b><br>053898              |                         |   |  |                                       |                         |           |
| Spindle STOP                                      |  |                                       | <b>814TQ25</b><br>047425              |                         |   |  |                                       |                         |           |
| ON-OFF, stay-put                                  |  | <b>899TQ18</b><br>089232              | <b>899TQ25</b><br>093063              |                         |  | <b>899LQ18</b><br>091008   | <b>899LQ25</b><br>093184              |                         |           |

**Notes**

The part numbers XQ18D-\*. \* or XQ25D-\*. \* must be supplemented when ordering:  
 1st wildcard (\*) Δ colour, e.g.: -R, -G, -B, -W, -Y, -S  
 2nd wildcard (\*) Δ File name generated by LabelEditor → Engineering

